




HIGH COOLING PERFORMANCE

HYDRAULIC RAMP WITH FOLDING LIP

PRODUCT DATA SHEET

RHL MODEL



HEADQUARTER

Polígono Gardotza, 1
48710 BERRIATUA
Bizkaia (Spain)

Tel: +34 94 603 62 00

e-mail: kide@kide.com
www.kide.com

RHL MODEL RAMP MANUAL AND INSTRUCTIONS

ON-SITE FASTENING AND ASSEMBLY

ATTENTION:

- . Before placing the platform in the pit, remove the electrical cable to provide a temporary power supply.
- . Secure in place and weld, as shown in the attached diagram.
- . Insert the cable into the hose.
- . Secure the electrical panel to the wall above the hose outlet.
- . Secure the tube to the hose outlet up to the panel to pass the cable through.
- . Connect according to the attached diagram and test the platform.
- . The RHL model is fully automatic and verified in our factory. Our operators check the machine once it has been assembled, however, a final adjustment may be necessary once it is put into operation.

INCIDENTS OR MINOR FAULTS IN THE HYDRAULIC SYSTEM

ATTENTION:

The hydraulic unit's sole function is to lift the ramp onto the lorry. It must never be used to lift loads.

REGULATION OF DESCENT SPEED

If the descent speed is too fast, the hose break safety system will activate and block the ramp. Adjust the screw and nut until the correct descent speed is achieved.

REGULATION OF THE OPENING SPEED OF THE NAIL

Adjust the adjustment nut on the distributor block.

The opening speed should be uniform without hitting the ramp when reaching its open position.

HEADQUARTER

RHL MODEL RAMP USAGE SHEET

1 | FIELD OF USE

The loading ramp allows goods to be moved from a vehicle to the warehouse or vice versa.

2 | DELIVERY

The RHL model is fully automatic and verified in our factory.

3 | OPERATING INSTRUCTIONS

- . Centre the vehicle against the rubber bumpers on the ramp.
- . Switch off the engine, apply the handbrake and chock the wheels.
- . Press the up button until the lip is fully open. Release the button and the ramp will slowly descend onto the lorry platform.
- . At the end of the operation, press the up button again until the lip returns to the vertical position with the ramp platform just above the dock. Release the button and the ramp will return to its resting position.

4 | PRECAUTIONS FOR USE

- . Before each manoeuvre, check that no one is in the work area.
- . Ensure that the claw is at least 50 mm above the lorry before starting work.
- . Drive the forklifts slowly onto the platform...
- . At the end of the operation, check that the claw is properly engaged and that the enclosure is secure.

5 | MAINTENANCE AND CONTROL

- . A maintenance bar allows access to the underside of the platform.
- . Check the lubrication points and oil level every month.

6 | IN CASE OF FAULT – TECHNICAL SERVICE



- . Prohibit the use of the ramp.
- . Call our technical service.
- . Write down the serial number of the ramp.

HEADQUARTER

HYDRAULIC RAMP

RHL MODEL

TECHNICAL DATA

Features			
Dimensions - standard nominal length	2500 mm	3000 mm	3500 mm
Dimensions - platform width	1800 mm	2000 mm	2200 mm
Vertical working range	Above the pier	0-400 mm	
	Under the pier	0-250 mm	
Truck tilt absorption	100 mm		
Platform plate	Standard	Thickness 6/8	
	For galvanising	Thickness 8/10	
Lip plate	Thickness 13/15		
Surface treatment	Painted RAL 7016	RAL 7016 Gris antracita	Hot-dip galvanised
Painting	Two-component polyurethane		
Galvanising surface treatment	Hot-dip galvanised 80 µm		

Hydraulic and electrical characteristics			
Load capacity	60kN (6TM)	100 kN (10 TM)	160 kN (16 TM)
Hydraulic motor	1,1 kW= 1,5 CV		
Working pressure	140 bares		
Power supply	380 V three-phase / 230V three-phase 50 Hz		
Manoeuvre	Man present	Emergency shutdown	
Frame protection	IP54		
Type of oil	Hydraulic HM46	5-litre tank	
Solenoid valve	24V/CC 18 W		
Lifting cylinder (safety valve in case of hose breakage)	50x470	1 unit in 2500/3000/3500 mm	
		2 unit in 4000/4500 mm	
Lip cylinder	30x105		
Hoses	180 bares		
Frame components	Start-up light, isolator, thermal switch, contactor, fuses, transformer, safety limit switch, circuit breaker, emergency stop		


HEADQUARTER

HYDRAULIC RAMP

RHL MODEL

PLATFORM AND UPPER NAIL

- . 6 Tm. Punctual on 3 or 4 wheels depending on the type of forklift.
- . Tear-shaped upper platform plate. (Thickness 6/8).
- . Tear-shaped peak plate, with a bend 150 mm from the end supporting the lorry. (Thickness 13/15).
- . Reinforcement on the upper plate of 8 IPN-100mm, plus two 80 angles and 2 side plates of 3mm in sizes 2500-3000 and 3500mm; when the sizes are 4000-4500mm, the 8 IPNs are 120mm.
- . In all sizes, the upper tear plate is a single piece without joints.
- . Anti-shear safety skirts.
- . Safety bar for maintenance work.
- . Rear hinge with 5 support points.
- . **Load capacity: 6 tonnes dynamic and 9 tonnes static.**
- . **Load capacity: 10 tonnes dynamic and 12 tonnes static.**
- . **Load capacity: 16 tonnes dynamic and 18 tonnes static.**




APPROXIMATE WEIGHT

Long 2500 mm	850 kgs
Long 3000 mm	950 kgs
Long 3500 mm	1100 kgs
Long 4000 mm	1250 kgs
Long 4500 mm	1400 kgs

RAMP MEASUREMENTS

PIT MEASUREMENTS

RAMP MEASUREMENTS	PIT MEASUREMENTS
ANxLxAL	ANxLxAL
2000X2500X600	2040X2300X610
2000X3000X600	2040X2800X610
2000X3500X600	2040X3300X610



HEADQUARTER

HYDRAULIC RAMP

RHL MODEL

OPTIONS

Lips

500 mm lip

Beveled lip at the ends

2 movable brackets, 150 mm

Surface area

Special RAL Hot-dip galvanised Top in 304 stainless steel

Backstage

Pre-frame angle 80x80

Box Model Pegasus metal drawer

Bench Box model with trapdoor Simple Double aisle

Others

Double cylinder Rings for unloading Sealing brushes

Equipment

Bumpers

Metallic 460x240x100 Painted Zinc plating Galvanised Reinforced


250x250x100 500x250x100 100x120x400

Polyurethane 80x80x400 Rollers 84x380x140

Chock system kit Polyurethane shim

LED spotlight Fan

Truck guides Zinc-coated Yellow graffiti Yellow/black graffiti




HEADQUARTER

HYDRAULIC RAMP

RHL MODEL

WELDING DIAGRAM



HEADQUARTER

HYDRAULIC RAMP

RHL MODEL



RAMPA ELEVADORA CONEXIÓN DEL BORNERO

<input type="checkbox"/>	L1	ENTRADA	3PH 400V
<input type="checkbox"/>	L2	ENTREE	50 HZ - 60HZ
<input type="checkbox"/>	L3	IN	
<input type="checkbox"/>	PE		

<input type="checkbox"/>	U	ALIMENTACIÓN AL MOTOR
<input type="checkbox"/>	V	ALIMENTATION MOTEUR
<input type="checkbox"/>	W	ENGINE SUPPLY
<input type="checkbox"/>	PE	

<input type="checkbox"/>	1	FCL FINAL DE CARRERA SUBIR NC
<input type="checkbox"/>		FCL FDC HAUT NC
<input type="checkbox"/>	2	FCL FCD HIGH NC

<input type="checkbox"/>	4	EVI ALIMENTACIÓN ELECTROVALVULA 24VAC
<input type="checkbox"/>		EVI ALIMENTATION ELECTROVANNE 24VAC
<input type="checkbox"/>	5	EVI ELECTROVALVE SUPPLY 24VAC

18W MAX


Fecha	16/07/2014	Fecha	16/07/2014	Fecha	16/07/2014	Fecha	16/07/2014
Resp.		Revisión		Revisión		Revisión	
Original		Original		Original		Original	
Nombre		Nombre		Nombre		Nombre	
Fecha		Fecha		Fecha		Fecha	
Cambio		Cambio		Cambio		Cambio	
Sustituido por		Sustituido por		Sustituido por		Sustituido por	
PLAUT		PLAUT		PLAUT		PLAUT	
Dase		Dase		Dase		Dase	
Electricidad y Electrónica		Electricidad y Electrónica		Electricidad y Electrónica		Electricidad y Electrónica	
CONEXIONADO DE BORNES		CONEXIONADO DE BORNES		CONEXIONADO DE BORNES		CONEXIONADO DE BORNES	
Ind.		Ind.		Ind.		Ind.	
IEC: 60004		IEC: 60004		IEC: 60004		IEC: 60004	
+ 9P1		+ 9P1		+ 9P1		+ 9P1	
Hoge		Hoge		Hoge		Hoge	
3		3		3		3	

HEADQUARTER

HINGE MOUNTING INSTRUCTIONS

- 1 | Introduce both hinges into the cover rails, as shown on the figure, so that the hinge insert coincide with the cover hole.
- 2 | Introduce the second halves of the hinges into the bottom rails and make them slide down to the bottom.
- 3 | Keeping the cover perpendicular to the bottom introduce the metal screw as shown on the figure.

To remove the hinge from the cover, insert a screwdriver into the space between the bottom of the cover and the hinge edge and push towards outside.



HYDRAULIC RAMP

RHL MODEL


RAMP BREAKDOWN



- 1
- 2
- 3

- 1. **A150101040200** Lip 2000x400
- 2. **A120602042000** Lip kit*
- 3. **A150317001200** Mobile skirt (x2)

*Lip + cylinder ears + lip + hinges + handrails



A160801010000 Hydraulic Kit

- 1. **A170402000015** Electrical panel RHL
- 2. **A160602000015** Hydraulic unit
- 3. **A160102050470** RHL 50x470 lifting cylinder
- 4. **A160102LABRHL** Lip cylinder 30x105
- 5. **A160202001500** RHL 1500 hose/
A160202002150 Lip hose 2150
- 6. **A150305000000** P.0005 Switchboard support
- 7. Lip cylinder support
- 8. Lifting cylinder support

HEADQUARTER


HYDRAULIC RAMP

RHL MODEL




Lip cylinder support

A15030600000 P.006 Ears (x4)
 Shaft Ø 16 (x2)
 Fin pin (x4)





Lifting cylinder support

A15030100000 P.0001 Support (x2)
A15030400000 P.0004 Upper bracket (x2)
A150400010030 Recessed shaft Ø 30
 Shaft Ø 25
 Flap pin (x2)



1. **A170402000020** Box with cover
2. **A280000000023** Disconnector
3. **A280000000021** LED pilot light
4. **A280000000022** Red mushroom push button
5. **A280000000041** Complete push button



A170802024250 Rectifier connector
 12V-24V-250V

A170600000024 Coil 24 DC



A160502000000 Complete solenoid valve

HEADQUARTER

BASIC GUIDE TO RESOLVING RAMP INCIDENTS



Do not press the emergency button, except in an emergency. Pressing it causes the cylinders to retain the oil pressure inside them and exerts unwanted force on parts of the ramp. The ramp lowers by gravity.

RAMP REGULATIONS

- 1 | ADJUSTING THE DESCENT SPEED: open by unscrewing the throttle to make it go faster and close by screwing it to make it go slower.
- 2 | ADJUSTING THE LIP SPEED: open by unscrewing the throttle to make it go faster and close by screwing it to make it go slower.

POSSIBLE INCIDENTS

A | THE MACHINE DOES NOT RAISE:

:: If the motor turns:

- . The phase may need to be changed in the electrical panel.
- . Check that there is oil.

:: If the motor does not turn:



- . Check connections and power supply.
- . Check that the cable is not cut.

B | THE MACHINE DOES NOT DESCEND:

- . Check that the emergency button has not been activated.
- . Check that the solenoid valve is receiving power. Check the wiring and coil.
- . If it is receiving power, check that the choke is not too tight. It is factory-set.

C | THE LIP DOES NOT OPEN:

- . Check for oil.
- . Check that the valve is not too tight.



HEADQUARTER



HYDRAULIC RAMP

RHL MODEL

Continuous coil has rectifier (System Dock ramps case)

Alternating coil does NOT have rectifier (not common).

Normally open solenoid valve: its function is to tell the hydraulic unit to change the circuit so that the machine can lower.



HEADQUARTER